



DIY APRON

WHAT YOU'LL NEED


- A simple cotton dish towel (approx. 60 cm or 2 feet square)
- 2 (shoe)laces of about 115 cm long
- A large safety pin
- A sewing machine




Fold over the top corners of the towel.




Pin and sew through about 1.5 cm or 3/4 inch from the edge, on both corners.



Fold up the bottom of the dish towel.



Pin and sew the edges. Sew 3 lines down the front to create pockets.



Thread a shoe lace through each armhole / sleeve using a safety pin. Tie shoe laces at the top to create neck tie! Leave long strings hanging from both sides.



Ready to wear!